

Battery installation

- Before battery installation, press right or left handle on the control panel and make sure that indicator light up. Watch around when install that your fingers do not close two copper pipes, because it may lead to improper work of remote control.
- After batteries installation keep your fingers and other body parts far from rotating propellers.

Picture 1

Picture 2

Picture 3

1. Put the boat to the platform and remove a cap.

2. Open the cap of battery slot and put the battery in.

3. Connect the battery to the socket of the receiving mechanism

Picture 4

4. Replace the battery precisely inside the boat and make sure it does not move.

cabin installation

Picture 1

Picture 2

Set the shutter of the top part of boat into the housing as it shown at the picture, fully slide it in and click on the cover, then turn the shutter button up. (Remove the upper part of the boat in reverse order.)

antenna installation

Picture 1

Picture 2

Install the receiving wire in the channel on the antenna, then install the antenna in the hole in the boat.

launching

This new model of high-speed boat has an automatic inclusion. When you launching the high-speed boat on the water, the water enters the two copper pipes and automatically switches on the power.

IMPORTANT:

1. Children before 14 need help of adults.
2. Do not play in the reservoir with people in.
3. Check out if there any obstacles in the water; if yes then do not play with boat there.
4. The range (radius) of this model is 80 meters. Do not exceed it to avoid loss of control.
5. Do not play with this boat more that 30 minutes, continue your play after the engine of the boat coos down.
6. Do not play with this boat in salty water; it may damage some of moving parts of the boat.